COMMUNICATIONS RESOURCE AVAILABILITY WORKSHEET

Frequency Band: TWO METER

Description: REPEATERS

Pg No	Channel Configuration	Channel Name/Trunked Radio System Talkgroup	Eligible Users	RX Freq N or W	RX Tone/NAC	TX Freq N or W	Tx Tone/NAC	Mode A, D or M	Remarks
1	REPEATER	PRIMARY	AMATEUR	146.880	CSQ	146.2800	88.5	A	WILLIAMS HILL
1	REPEATER	PRIMARY	AMATEUR	147.0900	CSQ	144.6900	88.5	A	ANNA
1	REPEATER	ALTERNATE	AMATEUR	147.3450	CSQ	147.9450	88.5	A	TUNNEL HILL
1	REPEATER	ALTERNATE	AMATEUR	146.8500	CSQ	146.2500	88.5	A	ALTO PASS
1	REPEATER	ALTERNATE	AMATEUR	146.8050	CSQ	146.8050	88.5	A	BENTON
1	REPEATER	ALTERNATE	AMATEUR	147.7300	CSQ	147.1300	88.5	A	CARBONDALE
1	REPEATER	ALTERNATE	AMATEUR	147.1800	CSQ	147.7800	88.5	A	CAIRO
1	REPEATER	ALTERNATE	AMATEUR	146.6400	CSQ	146.0400	88.5	A	MARION
1	REPEATER	ALTERNATE	AMATEUR	147.2250	CSQ	147.8250	123.0	A	METROPOLIS
1	REPEATER	ALTERNATE	AMATEUR	147.2550	CSQ	147.8550	118.8	A	OLIVE BRANCH
1	REPEATER	ALTERNATE	AMATEUR	147.0450	CSQ	147.6450	97.4	A	WEST FRANKFORT
1	REPEATER	ALTERNATE	AMATEUR	145.2500	CSQ	145.2500	77.0	A	ANNA

The convention calls for frequency lists to show four digits after the decimal place, followed by either an “N” or a “W”, depending on whether the frequency is narrow or wide band. Mode refers to either “A” or “D” indicating analog or digital (e.g. Project 25) or "M" indicating mixed mode. All channels are shown as if programmed in a control station, mobile or portable radio. Repeater and base stations must be programmed with the Rx and Tx reversed.